


# MBK-Z Series

ø32, ø40, ø50  
ø63, ø80, ø100

The Replacement Procedure is on p. 381

## Construction



- \* The numbers correspond with those in the "Construction" of the MBK-Z series in the **Web catalog**.
- \* Replaceable with the rod boot assembly
- For details on replacement part numbers, refer to page 245.

### Seal Kit List

No.	Description	Material	Qty.	Note
14	Rod seal	NBR	1	<b>17 is a non-replaceable part, so it is not included in the seal kit.</b>
15	Piston seal	NBR	1	
16	Cushion seal	Urethane	2	
17	Cushion valve seal	NBR	2	
18	Cylinder tube gasket	NBR	2	

### Replacement Parts: Seal Kit

Bore size (mm)	Part no.	Contents
32	MBK32Z-PS	Set of nos. 14, 15, 16, 18
40	MBK40Z-PS	
50	MBK50Z-PS	
63	MBK63Z-PS	
80	MBK80Z-PS	
100	MBK100Z-PS	

\* The seal kit includes 14, 15, 16, and 18. Order the seal kit based on each bore size.

\* The seal kit includes a grease pack (ø32 to ø50: 10 g, ø63, ø80: 20 g, ø100: 30 g).

Order with one of the following part numbers when only the grease pack is required.

**Grease pack part no.:** GR-S-010 (10 g)  
GR-S-020 (20 g)

Actuators

Rotary Actuators  
Air Grippers

Modular F.R.L.  
Pressure Control Equipment

Air Preparation Equipment

Industrial Filters

Replacement Procedure

Actuators

Rotary Actuators  
Air Grippers

Modular F.R.L.  
Pressure Control Equipment

Air Preparation Equipment  
Industrial Filters